

**Using the Corvette navigation system - Index and Quick reference. by Paul Pearson**

<b><u>Section</u></b>	<b><u>Document</u></b>	<b><u>'08 Nav manual reference</u></b>	<b><u>Page</u></b>
<b>Section 1. Setting up the navigation system. – Part 1</b>		<b>1-7</b>	<b>page 5.</b>
Setting the correct region		<b>1-7</b>	page 6.
User settings		<b>2-41</b>	page 7.
Quick points of interest		<b>2-37</b>	page 8.
<b>Section 2 Entering a destination</b>	<b>Part 1,</b>	<b>2-4</b>	<b>page 9.</b>
Menu selections			page 9
Entering an address		<b>2-7</b>	page 10.
Route options - route info		<b>2-22</b>	page 12.
Route options – cancel guidance		<b>1-11</b>	page 14
Display route		<b>2-46</b>	page 15
Turn list		<b>2-46</b>	page 15
<b>Section 3 Other means of destination entry</b>	<b>Part 2</b>		<b>page 17.</b>
Select from map		<b>2-11</b>	page 18.
Phone number		<b>2-17</b>	page 19.
<b>Section 4. Points of Interest</b>	<b>Part 2.</b>	<b>2-8</b>	<b>page 21.</b>
POI by city or name		<b>2-8</b>	page 22.
POI by Quick POI or map			page 25.
POI Info			page 26.
POI voice recognition commands		<b>4-8</b>	page 27.
<b>Section 5. Waypoints</b>	<b>Part 3</b>		<b>page 28.</b>
Storing waypoints via the Enter Destination menu		<b>2-30</b>	page 29.
Storing waypoints via the Destination and Waypoint menu			page 31.
<b>Section 6. Storing a memory point</b>	<b>Part 3</b>	<b>2-24</b>	<b>page 32.</b>
Storing a memory point from the map screen			page 34.
Adding or editing a memory point name		<b>2-23</b>	page 36.
Adding or editing a memory point phone number		<b>2-26</b>	page 36.
Deleting one or all memory points		<b>2-27</b>	page 38.
<b>Section 7. Previous destinations</b>	<b>Part 4</b>		<b>page 39</b>
Using a previous start point		<b>2-14</b>	page 40.
Using a previous destination from the list		<b>2-14</b>	page 41.
<b>Section 8. Preset destinations</b>	<b>Part 4</b>		<b>page 42.</b>
Entering a Preset destination		<b>2-33</b>	page 42.
Editing a Preset destination		<b>2-34</b>	page 43.
Using a preset destination.		<b>2-19</b>	page 44.
<b>Section 9. Map modes</b>	<b>Part 5</b>		<b>page 46.</b>
Single map mode		<b>2-56</b>	page 47.
Dual map mode		<b>2-57</b>	page 48.
Turn list map mode		<b>2-57</b>	page 48.
Next turn map mode		<b>2-57</b>	page 49.
Highway guidance map mode		<b>2-58</b>	page 49.
<b>Section 10. Functions avail. while driving.</b>	<b>Part 6</b>		<b>page 51.</b>
<b>Navigation System quick reference sheet</b>			<b>page 58.</b>